广州达创条码技术有限公司
广州市天河区中山大道中 38 号花明大厦 512－513
TEL：020-83695256　FAX：020-87059830　WEB：http://www.51tiaoma.com


CODESOFT6 中文使用手册

软件的安装　认识界面　标签格式的建立


建立标签　标签打印　常见软件故障

一: 软件的安装

在供应商提供的条码软件光盘里, 找到可执行文件 SETUP. EXE, 并运行.



在语言选择栏中选取语言后, 确定.




按下一步安装.

在指定的路径下安装,直到完成.

安装完成后,在安装盘下找到文件 Csutil.dll,将它复制到安装好的根目录下,完装完成.

注:如果没有进行以上步骤,打开软件时将会提示没有发现加密狗,则程序只能在演示状态下使用,且文档不能保存.如图



二:认识介面


主视窗介绍

(1) 目录列




目录列包括:档案,编辑,视图,插入,格式,工具,表格,视窗及说明


(2) 工具列



(3) 视检检列



(4) 物件列



(5) 旋转按钮



这个按钮可让你将屏幕上的内容旋转 90^0,1800,270^0或 360^0


以鼠标左键点旋转按钮, 可将内容向左转 $90^{0.}$ **以鼠标右键点旋转按钮, 可将内容向右转** $90^{0.}$

三: 标签格式的建立


1. 设定界面

按工具栏中的,弹出 PAGE SETUP 对话框,可设定标签大小.


⑴设定标签面纸



(2) 设定标签底纸




(3) 设定边距



按照以上要求设定好标签后,可以看到工作区域和标签大小一致


2:添加,设定打印机

按选择打印机按钮,可以选择和添加没有的打印机.




设定打印机,如下

(1) 一般选项


设定打印速度
设定打印浓度
旋转 180O后打印
镜像打印
重新载入图形
Printer settings - Zebra 170XiIII
General
Advanced
Environment
Fonts
50.8
Print speed (mm)/s
0
Temperature
Paper feed mode
Tear off
180° rotation
Optimize
Back feed off
Pause
Flip (transparent media)
Cut after batch
0
Printed pages between pauses/cuts
Xi
选择出纸方式
Images
Reload images at next print time
DRAM
Destination memory
Set date/time...
Network settings...
OK
Cancel
Help

(2) 高级选项


调整打印起始位
设定最大图形数
Printer settings - Zebra 170XiIII
General
Advanced
Environment
Fonts
0.0
Adjust origin vertical(mm)
0
Country code
10
Timeout (s)
0
Maximum number of images
Download images in the buffer
Send modified data only
Check printer status
Activate image compression
~ = DLE, ^=RS
Black / white reversed
Print mode
Thermal transfer
Direct thermal
选择打印方式
Paper calibration
Initialization sequence:

四: 建立标签


1. **建立文字**

(1) 选择文字生成工具 ,然后点击工作区域内部.

(2) 输入内容

(3) 选用选择工具,点击刚才建立的文字.


(4) 进入对话框




2. **数字变量的制作**

(1) 文字生成工具 ,将光标移到工作区域,点击一次.


(2) 在生成的文字输入框中,按鼠标右键,并选择文字生成工具




在如下对话框中,选择 DATA SOURCE 选项卡,选择 variable data 变更生成器



用鼠标右键在 FREE(1)中添加变量 VAR0,双击刚生成 的变量 VAR0,得到如下对话框.








3:组合数字变量的制作


例: 做数字变量AACD001BB23005


方法 1(图例示步骤)



File Edit View Object Merge
Document1
Text generation
Selection tool
Cut Ctrl+X
Copy Ctrl+C
Paste Ctrl+V
Properties...
Page setup...
Text
Character Paragraph Data source
Fixed data
Variable data
Database (None)
Date (None)
Formula (None)
Form (None)
Table lookup (None)
Counter (None)
Free (2)
Var0
Var1
OK Cancel Help
Var0
Input Output Counter
Variable value
Local 001
Shared
Restore after printing
Delete spaces
Display in Form
Prompt
Input format
Minimum length
Pick list
OK Cancel Help



Var0
Input
Output
Counter
Maximum length
7
Prefix
AACD
Suffix
Display decimals
Number of decimals
Decimal separator
Thousand separator
Padding character
None
Character
0
Pad up to X characters
X=
3
Include in the log file
OK
Cancel
Help
Var0
Input
Output
Counter
Counter
ISO counter
Type
Decimal
Increment
+1
Reset the counter to
000
after
999
Increment after
Having printed
1
label(s)
Each reset of
OK
Cancel
Help
Var1
Input
Output
Counter
Variable value
Local
005
Shared
Delete spaces
Restore after printing
Display in Form
Prompt
Input format
Minimum length
Pick list
OK
Cancel
Help
Var1
Input
Output
Counter
Maximum length
7
Prefix
8823
Suffix
Display decimals
Number of decimals
Decimal separator
Thousand separator
Padding character
None
Character
0
Pad up to X characters
X=
3
Include in the log file
OK
Cancel
Help



Var1
Input
Output
Counter
Counter
ISO counter
Type
Decimal
Increment
+1
Reset the counter to
000
after
999
Increment after
Having printed
1
label(s)
Each reset of
OK
Cancel
Help


Var0 Var1


Var0 Var1



Text
Character
Paragraph
Data source
Fixed data
Variable data
Database (None)
Date (None)
Formula (1)
Formula0
Form (None)
Table lookup (None)
Counter (None)
Free (2)
OK
Cancel
Help



Formula0
Formula
Output
Counter
Var0 & Var1
Check characte
Conversion
Date & Time
Logical
Math
Text
Operators
Variables
@INTERCUT
@LABELCPY
@LABNAME
@PAGECPY
@SERIALQTY
Var0
Var1
Test
Undo
Insert
OK
Cancel
Help



AACD0018823005
AACD001
8823005

方法 2

只做两个变量，不加前缀，分别得到 VAR0 和 VAR1 两个变量.










4.条码标签制作

条码标签制作与数字标签不同的地方在于选取制工具不同. 其余都相同.





Barcode
Code
Options
Human readable
Character
Data source
Generated by the printer
Include the check character
Position
None
Below
Above
Free
Alignment
Left
Centered
Right
Distance from the bars(mm)
0.00
OK
Cancel
Help
条码内容所在的位置
条码内容对齐方式
条码与文字和距离


Barcode
Code
Options
Human readable
Character
Data source
Printer
Graphic
point size
Font
Height
Size
Arial
Arial
Arial Black
Arial Narrow
Basemic
8
9
10
11
12
14
16
Subset
西方
Style
Bold
Italic
Underline
ABCDEFGHIJKLMNOPQRSTU
0123456 abcdefgh
Height
3.8
Width %
100
OK
Cancel
Help
打印机字体
Windows 字体
字体类型
字体样式
字体高度
字体宽度

五：标签打印。

打印标签可按 F6 或打印工具按钮，出现如下打印对话框。



六:常见的软件问题

1:打印不清楚:

打印内容出现较多白点.可将打印机的浓度调高,使打印清昕.

2:打印过程中出现打印内容部分打印不出,(条码或文字)

停机,清除已经发送的打印内容,在打印命令发出这前,重新载入图形.